

# KUFU

## DRAWER SYSTEM

# QUICK START GUIDE

### *Using the Drawer with the Grip / Handle and Latch:*

- The KUFU Drawer has a spring loaded Handle & Grip, with a connected Latch underneath the sliding Drawer.
- The Latch will spring into any available locking or rest position to prevent the Drawer from moving or sliding, this also includes the closed position.
- Firmly squeeze the Handle & Grip on the Drawer Front to open and close the Drawer. Use two hands if required to fully open the connected Latch.
- Move the Drawer to the desired position and release the Grip, then gently move the Drawer until a lock rest position, the Latch will clunk into the rest position.
- **WARNING:** Do not forcefully slide or skip, or slam the Latch into / past / over a rest position. The Latch can damage the rest positions of the Drawer Carcass.
- When closing the Drawer remember to release the Grip to allow the Latch to find the closed rest position, use two hands if required to move the Drawer Internals because Drawer seal can prevent latching.

